



# Whirlpool®

WTW4307S

**4.2–4.3 CU. FT. WHIRLPOOL® TOP LOAD  
WASHER WITH 2-IN-1 REMOVABLE  
AGITATOR AND SOFT CLOSE GLASS LID**

Dimensions: h: 42.625" w: 27.125" d: 26.25"  
Colors:



## START THE CONVERSATION

How often do you wash large or bulky items like comforters, sleeping bags, or king-sized sheets?


## TOP FEATURES



1

### 2-IN-1 REMOVABLE AGITATOR

The 2 in 1 Removable Agitator lets you choose how you wash. Easily swap in the agitator to help with soils or remove for extra capacity to fit large & bulky items.



2

### PRESOAK OPTION

Gently help release soils with a 30 minute presoak and wash all in one cycle



3

### SOFT-CLOSE GLASS LID

Easily check on your laundry with a soft-close, glass lid

## DID YOU KNOW?

The 2 in 1 Removable Agitator is great for shared households (different laundry needs in one home).

## HOW TO DEMONSTRATE



### 2-IN-1 REMOVABLE AGITATOR

Ask the customer to squeeze the handle on the agitator, then have them rotate it 90 degrees and lift to remove it. Explain how you can wash clothes any way they want with either an agitator or an impeller design.

## ADDITIONAL PRODUCTS TO CONSIDER

Be sure to tune into your customers' shopping priorities to bundle products across categories



ALSO AVAILABLE / STEP UP  
[WTW5020S](#)



LAUNDRY / PAIR WITH  
[WED4307S](#)



LAUNDRY / PAIR WITH (GAS)  
[WGD4307S](#)